BRADY
WHEN PERFORMANCE MATTERS MOST™

Entrytag®

How to use guide

Entrytag® is a purpose designed status tagging system to control confined space entry in conjunction with a permit to work system. Entrytag® provides a methodical way to ensure safety is maintained at every stage.

The Entrytag® system should be positioned at the entrance to the confined space, to inform all personnel of the minimum requirements for entry, the type of work being undertaken, and all the other salient details or to prohibit entry entirely.

Many customers also adopt the Man in Confined Space Tag in conjunction with Entrytag®. The approved person(s) each have a dedicated Man in Confined Space Tag (containing their details) and attach it to the Entrytag® before entering and remove the tag when leaving the confined space.

By counting the number of Man in Confined Space Tags at the point of entry, it is instantly clear how many people are working in the confined space.

Stage 01

Empty Entrytag® holder is attached to the entrance of the confined space. Before inspection the prohibition symbol and words “do not enter” are clearly displayed.

Stage 02

A competent person* is to complete the inspection record and place the Entrytag® insert into holder if the area passes inspection.

Stage 03

Inspections should be conducted at regular intervals as per regulations and recorded on the Entrytag® insert.

Stage 04

If the area fails inspection, remove the Entrytag® insert to display “do not enter” on the holder.

* The term competent person is generally accepted as someone who has the necessary experience, training, qualifications and/or skills to do whatever task is required, competently.

Hung

Cable Tie

Magnetic Strip

Adhesive Strip

Holder Attachment Options

The Entrytag® provides a number of different options of attachment to display the latest status at the entrance of the confined space.

Entrytag®

Technical specifications

A complete confined space status tagging system to help prevent accidents and efficiently manage inspection procedures. The Entrytag® system is designed to operate alongside existing permit to work systems and other control procedures employed on site. It uses our unique holder and insert system to ensure the latest status is instantly visible at the point of use.

The Holder

The Insert

Holder Specifications

- TEMPERATURE TOLERANCE: -5°C to +65°C
- MATERIAL: ABS
- DIMENSIONS: 285mm x 151mm
- ATTACHMENT OPTIONS: Hung, cable tie, magnetic strip, adhesive strip.

Insert Specifications

- TEMPERATURE TOLERANCE: Max temperature 125°C
- MATERIAL: Polypropylene
- DIMENSIONS: 193mm x 144mm.

Simple to Use

- Clear format to record equipment details
- Illustrated tick boxes indicating the safety equipment required
- Record notes / requirements regarding the area of work tagged
- Record and date up to 42 shift inspections.

BRADY®
WHEN PERFORMANCE MATTERS MOST™

Brady EMEA

Africa	+971 4881 2524	Middle East	+971 4881 2524
Belgium	+32 (0) 52 45 78 11	Norway	+47 70 13 40 00
Denmark	+45 66 14 44 00	Slovakia	+421 2 3300 4800
France	+33 (0) 3 20 76 94 48	Spain	+34 900 902 993
Germany	+49 (0) 6103 7598 660	Sweden	+46 (0) 8 590 057 30
Hungary	+36 23 500 275	Turkey	+90 212 264 02 20
Italy	+39 02 26 00 00 22	UK	+44 (0) 1295 228 288

Your Brady Distributor

© 2013 Brady Worldwide Inc. All rights reserved.